

SCENE INDICATOR 26 SCENE TIMER 27 30 -SW4 SW3 SW2 SW1 Х R PG G 36 38 34 32 MANUAL SCENE SELECTOR 40

FIG. 3





FIG. 2






FIG. 5